
PFB D01 D02


Dimensions [mm]

Installation











Fuse link replacement


Disassembly



Unscrew the cap




Replace the fuse link



Screw the cap back

(€



Using a screwdriver pull down on the plastic snap-on unit

